



INSTALLATION INSTRUCTIONS

Tech Support
856-768-5700 EXT 2
TechSupport@LEDGlow.com

Limited Warranty and Disclaimer

All LEDGlow Lighting, LLC. products come with a one year limited warranty on the internal parts of the product. This warranty starts from the date of purchase. LEDGlow Lighting, LLC. will replace or repair any qualifying defective product received by the company before the end of the warranty period. Installation of this product must be performed by a licensed professional. Should the failure of the product be the result of damage occurring as a result of improper installation, alteration of the product or an act or omission on the part of the consumer, this warranty is void. LEDGlow Lighting, LLC. shall not be responsible for any consequential damages which arise from the use and/or installation of the product. If the kit is installed in any manner other than specified, LEDGlow Lighting, LLC. reserves the right to deny any warranty claims at the discretion of the technical support department. The one year warranty is not transferable and is valid for up to one year from the original date of purchase. Any product return must include the original packaging, a statement of the alleged defect and an RMA number must be provided. All RMA numbers are valid for 14 days from issued date. Upon receipt of the returned product, the company will test the product for defect. If the results of the testing do not support the warranty claim, do not reveal any defect or indicate consumer negligence in the installation and handling of the product, then the product will be returned to you and you will be charged a reshipping fee. If the product is returned from an address within the continental United States, within the first 14 days after purchase, and is found to be defective, LEDGlow Lighting, LLC. will cover the cost of the return shipping with an emailed return label. This offer is only valid for the continental US. All international shipping, customs fees and/or duty charges are solely the responsibility of the consumer.

Additional Disclaimer Terms


Lights are for off road use only; please check your local and state laws for the proper use of this product.

- Improper installation of electricity-using products such as lighting may cause damage to any vehicle or device to which the improperly handled or installed lighting is attached.
- Improperly installed product may cause electrical injury to persons.
- It is recommended that the kit be installed by a licensed professional.
- LEDGlow Lighting, LLC. assumes no liability for the installation of the product.
- Warranty or liability will not exceed the product purchase price which shall be the buyer's sole and exclusive remedy.

THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE WARRANTIES DESCRIBED ON THE FACE HEREOF INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. (LEDGlow Lighting, LLC. AT ITS DISCRETION, MAY PROVIDE REMEDY OF RETURN OF PURCHASE PRICE OR REPAIR OR REPLACEMENT OF DEFECTIVE PRODUCT AS BUYERS SOLE AND EXCLUSIVE REMEDY.)

LEDGlow Lighting, LLC.
150 Cooper Road - Suite A-2 West Berlin, NJ 08091

LED Tailgate Light Bar with Amber Turn Signal

- Inspect and check the operation of the light strip by temporarily connecting the light strip to the trailer tow harness before installing it on the vehicle.
 - **(VEHICLES WIRED FOR A TRAILER TOW HARNESS)** If your vehicle is wired for a trailer, you can simply plug the flat 4 pin wire connector in and test the running, brake and turn signal lights for proper operation.
 - **(VEHICLES NOT WIRED FOR A TRAILER TOW HARNESS)** If your vehicle is not wired for a trailer, you have to wire the light into the vehicle and test the running, brake and turn signal lights for proper operation. You can use a flat 4 pin trailer tow harness to splice into the vehicle's wires. Refer to your vehicle's service manual for a wire schematic for correct wire placement.
 - Each Tailgate strip is wired with a standard flat 4 pin trailer connection harness:
 - a. Pin 1 -----Ground
 - b. Pin 2 -----Running Lamp
 - c. Pin 3 -----Left Turn Signal & Brake Light
 - d. Pin 4 -----Right Turn Signal & Brake Light
- 
- You must connect the additional red wire to a switched ignition power source. You can use a multi-meter to locate a 12 volt wire at the rear of the vehicle that has 12 volts when the key is on and 0 volts when the key is off. If you run a wire from another source on the vehicle, you must install a 10 amp fuse within 6 inches of the power source. Use a wire connector to connect the wire to a source that may be at the rear of the vehicle. Use electrical tape to seal the connection. You may also solder and heat shrink the connection. Refer to your vehicle's service manual for a wire schematic for correct wire placement.
 - You must connect the additional white wire to your existing reverse light power wire. Use a wire connector to connect the white wire to the vehicle. Use electrical tape to seal the connection. You may also solder and heat shrink the connection. Refer to your vehicle's service manual for a wire schematic for correct wire placement.
 - Once everything is tested, you can mount the light strip to the vehicle using the supplied double sided tape, making sure to clean the surface to remove any dirt and oil using an alcohol cleaning product. You can also remove the mounting tabs from the strip and use self-tapping screws to attach the strip directly to the vehicle. (Drilling may be required)
 - Once attached, you want to retest the light and make sure all of the functions work and then secure any excessive wire with wire ties.